


info@hydroholics.net www.hydroholics.net

Twin Pump Four Dump Configuration (Per Pump)

Not To Scale



Note:

- 1) Accumulator Tee, or a 3/8 #6 Elbow for line out cylinder
- 2) Accumulator on this end or opposite end the other will need 3/6 #6 straight or elbow for line out to cylinder
- 3) Check Valves
- 4) 3/8 Swivel, upward pressure directional flow
- 5) Return End of the Dump Requiring a 3/8 #6 Elbow (or straight)
- 6) Return Flow control valve, arrow shows return pressure direction

WWW.HYDROHOLICS.NET